



VistaEY2R_Demo

This package contains the demonstration software for the Vista Imaging VistaEY2R Biometric camera.

This software will work on the 32 and 64 bit versions of Windows XP through Windows 10.

The VistaEY2R_Demo package contains the following folders:

- Exe - Executable VcViewEY2R application and API Library DLL.
- Firmware - Current Firmware File and Update Utility
- Install - Driver installation files.
- Readme.pdf - This file.

Installation Procedure:

From the Install folder, run the VcInstallEY2R utility to Install and Uninstall the VistaEY2R drivers.

- On Windows XP, the user needs to be logged in with Administrator privileges.
- On Windows Vista, Windows 7, and Windows 8, the VcInstallEY2R program will ask for elevated privileges.

Run the Demo

Plug the camera in and wait a few seconds for device enumeration to complete.

From the Exe folder, run the VcViewEY2R.exe application.

Firmware Update

Start the VcViewEY2R application and select the Help\About menu to display the current camera version information. Verify that the camera firmware version matches the version in the Firmware folder. If not, refer to the VII FW Update Procedure document in the Firmware folder for firmware update instructions.

Face Tracking Software

The VcViewEY2R application uses third-party face tracking software from CyberExtruder, and is included in this demo package. However, a per-machine license is required to enable the face tracking software. Run the machineid.exe program to generate your unique machine identifier

and save the output as a text file. Then contact Vista Imaging or your distributor to obtain a license. Your license file must be renamed to "AureusSPI_License.txt" and resides in the same folder as the executable files. The "Enable Face Tracking" option in the VcViewEY2R control panel must be checked to enable face tracking.